



## Swiss Arms Burst Unit

Instructions.

Burst mode programming:

1. Install the Swiss Arms burst unit in serial with your battery
2. Switch the AEG to full auto mode
3. Pull the trigger and hold it until the guns stops shooting
4. Keep holding the trigger until three *beep's* are heard
5. Release the trigger
6. Pull the trigger and release it the number of times you want in your burst mode(1-12)
7. Pull the trigger and keep holding it until three *beep* are heard
8. Your gun is now programmed to shoot in burst mode

NB: For high ROF guns (>25), deduct one trigger pull when programming, to get the right number of shots fired in burst mode

Full auto mode programming:

1. Pull the trigger and hold it until the guns stops shooting
2. Keep holding the trigger until three *beep's* are heard
3. Release the trigger
4. Pull the trigger and keep holding it until a long *beep* is heard
5. Your gun is now in full auto mode

Features.

- Small size 45 x 17 x 8 mm.
- User Friendly programming. The AEG can be reprogrammet any time, by just using the trigger
- Programmable burst mode 1 - 12 shots
- Programmable full auto mode
- Equipped with battery low protection
- Equipped with up to date power MOSFET technology
- Active breaking technology employed
- Beep tone for programming and battery low warning
- Self adjusting battery status for various type battery

Specification.

- Operating voltage: 7,2 - 12 Volt
- Max. Continous current: 65 Amp
- Operating temperature: -10 °C - 70 °C
- Recommended battery type: 2 - 3 cell Lipo
- Battery low detection 6,6 or 9,9 Volt

SPARTAN  IMPORTS

Spartan Imports - True Møllevej 11, 8381 Tilst, Denmark - info@spartanimports.dk